

Wi-Fi Camera Quick Setting User Manual

Email: support@enster.com

Note:

1. This Wi-Fi camera only works with 2.4GHz Wi-Fi, but not 5GHz Wi-Fi!
2. Make sure camera is installed in the Wi-Fi range of 2.4GHz Router.
3. Connect camera to the power supply (DC 12V) then press the reset button 5s back to default.
4. PC client and Search Tool software don't support MAC OS, but it supports to view by login IP address on browser Safari.
5. Use micro-SD card Class-10 UHS-1 or high speed memory card.

If you have any question, please feel free to contact us!

1. Download the app on Smart phone

- way 1. Scan the following QR to download the APP CamHi
way 2. Search and download the APP CamHi from Google play store or App store



1

2. Wired connection setup steps (Recommend):


2.1 Connect camera to power and LAN



2.2 Connect smart phone to the same LAN




2.3 Open the CamHi APP




2.4 Add camera

2




2.5 Click Search Camera From LAN




2.6 Click the Device




2.9 Go to Wi-Fi setting



2.10 Click Wi-Fi manager, choose your router Wi-Fi




2.7 Click Done




2.8 Camera added successfully. Click Setting button

3



2.11 Input Wi-Fi password and click apply




2.12 When it shows "online" that means the camera connected

4


After setting Wi-Fi successfully, disconnect the Ethernet cable and wait 30s, then you can view camera wireless.

3. Wireless connection(For Option) setup steps:


3.1 connect camera to power, press and hold the reset button for 5 seconds, then you will hear a ticking from camera




3.2 Go to phone WLAN find and connect camera Wi-Fi begins with: IPCAM-XXXXXX



3.3 Input password: 01234567




3.4 Open the app, add camera




3.5 Click Search Camera From LAN

5



3.6 Click the Device





3.7 Click Done

Next, follow the steps same as 2.8, 2.9, 2.10, 2.11, 2.12 to connect Wi-Fi. After setting Wi-Fi successfully, disconnect the Ethernet cable and wait 30s, then you can view camera wireless.

4. APP functions introduction

Click setting button to go to camera settings



Note: There is a little difference between IOS and Android phone, the followings are for reference

6

Change Password: The default password is **admin**, it can be modified.

Alarm Setting: Activate the motion detection alarm

Action with Alarm: Set up motion detection alarm details

Recording Schedule: Set recording and recording schedule

Audio Setting: Set camera audio (please confirm if your camera supports audio)

Video Setting: Camera video details

Wi-Fi Setting: Showing the wifi that your camera is found

SD Card Setting: Check the SD card status and format the SD card

Time Setting: Set the camera time and time zone

Email Setting: Set up motion detection with email notification

FTP Setting: Set up FTP Server

System Setting: Reboot camera and reset camera to factory setting

Device Information: General information of camera

5. Live video stream on smart phone

① Mirror or Flip the image

② Zoom and Focus (please confirm if camera support)

③ Preset position (please confirm if camera support)

④ Light setting


⑤ Exit screen

⑥ audio on/off (please confirm if camera support)

⑦ Screenshot

⑧ Recording on/off

⑨ Resolution (HD: High definition, SD: Standard definition)



7

FAQ

How to insert the Micro SD card?

There are two situations: One is with rubber cover Fig 1
The other is without rubber cover Fig 2.



Fig.1 Remove the rubber cover and insert SD card



Fig.2 Remove screws and insert SD card

How to set Micro SD card record?

1. Format SD card at "SD Card Setting"

2. Click the icon ⑧ in Section 5 to record

How to know if the camera is powered?

Put camera in the dark to check if the IR lights is on or not (ir lights will turn red when it is on).

How to view Micro SD card record files?

On app home page, Click "Video", Click "Online", click camera ID to check all the record files list, click the record files then you can view video

How to share camera to other users?

You can share camera to other users by UID and password,

What to do if I forget camera password?

The default password is admin
You could only reset the camera if you forget the password.

How to find camera UID?

When camera connected, the camera's is UID:XXXX-XXXXXX-XXXXX

Tips:

For further operation, please kindly visit the web: www.enster.com

8