

How to view the video in the SD card?

There are two types to save video in the SD card, one is to save it in the SD card after the movement is triggered, and the other is to keep the video all day.

For the first type, you choose Settings>Action with Alarm>Open Alarm SD REC.

For the second type, select Settings>Recording Schedule>Select a stream>All day>Apply. The first stream video is clearer and requires 3.6G of memory for one day. The second stream requires 1.4G of memory for one day. After setting, you can view the video of the time period you need. View the alarm recording and scheduled recording in the homepage Video>Online>Select a specific time to view the alarm recording and scheduled recording.

Please refer to the picture below for details.





